

User Manual TASS GPS new 2021

GPS Vehicle Tracker User Manual

কিভাবে TASS GPS একটিভ করবেন:



ধাপঃ১

সর্ব প্রথমে আপনার মোবাইলে সফটওয়্যারটি ইন্সটল করুন।

www.tasslock.com/downloads

তারপর GPS থেকে সঠিক আইডিটি সফটওয়্যারে বসান।
লগইন করুন।

তারপর ১০০% সঠিক ভাবে GPS সিমকার্ড স্থাপন করুন।

তারপর খোলা আকাশের নিচে GPS ২ মিনিট রাখুন
পাওয়ার অবস্থায়। Location আসছে কিনা চেক করুন।

তারপর খুব সাবধানে GPS কভার ফিটিং করুন, ২ টি স্ক্রু
লাগিয়ে waterproof করুন।

ধাপঃ২

প্রথমে GPS এ একটি কল দিয়ে চেক করুন, যে কলটি যাচ্ছে কিনা। যদি কল না যায় তাহলে সিম
কার্ড বা পাওয়ার পায়নি।

তারপর, APP লগইন করে, **More Function** এ ক্লিক করে, **Special Alarm Setting** এ গিয়ে
আপনার মনমত সবকিছু সিলেক্ট করুন।

কল চেক করতে হলে One Key Sleep এ ক্লিক করে দেখুন ACC off হয়ে যাবে। তার পর গাড়ি একটু স্থান
থেকে সরান অথবা চাবি অন করে দেখুন। মোবাইলে কল আসবে। **Auto Arm time is 5 minutes.**



সেটিং সম্পন্ন হলো

হেল্পলাইন- 01681090909

[APP Download Link](#)

নিচে বাড়তি বৈশিষ্ট দেয়া হলো

User Manual TASS GPS new 2021

item	content	note
admin number	admin123456 18948742396	18948742396 is owner phone number
admin number	101#18948742396#	
SOS phone number1	102#18665810459#	
SOS phone number2	103#18925249950#	
Delete admin number	D101#	
Delete SOS phone number1	D102#	
Delete SOS phone number2	D103#	
Check special phone number	C10#	
restart device	CQ	
restart GPS	CQGPS	
password	password123456 654321	default password is 123456
APN	apn123456 internet.beeline.ru	apn check: https://apnsettings.gishan.net/
	apnuser123456 beeline	
	apnpasswd123456 beeline	
IP&Port	IP 113.98.254.178 7700	
Domain&Port	IP a.icargps.net 7700	
upload interval	FREQ,123456,30	upload interval when acc on
	STATIC,123456,40	upload interval when acc off
	upmove123456 120	upload interval when moving
language	109#	language switch to English
time zone	zone123456 e08	
parameter query	CXZT	
arm	SF	

User Manual TASS GPS new 2021

disarm	CF	
auto arm	ACCLOCK,123456,1	
auto disarm	ACCLOCK,123456,0	
Call shake alarm	122#	ON
	121#	OFF
SMS shake alarm	125#	ON
	126#	OFF
Vibration sensible	vibtime123456,n	n=1-15, default is 3s. 0=off
move alarm	move123456 300	300=300 meters
Google map link	G1234	
over speed alarm	speed123456 080	080=80km/h
IMEI	RIM#	
SOS alarm	sossms123456	turn off: no sossms123456
	soscall123456	turn off: no soscall123456
call back	88	